



TV FIELD STRENGTH METER


APM 742


SERVICE MANUAL


BLOCK DIAGRAM AF . ATTENUATOR AMPLIFIER SELECTOR YOLUME ATTENUATOR SMITCH 80...130 48,v 🕞 ATTENUATOR IF SWITCH SWITCH If = 38,9 AUDIO 108.CO STRINE RESIZER UNIT IF AMPLIFIER LOGIC →) YOLT. CIRCUIT FREQUENCYMETER O CONT. I TELETEXT A10 E 0 VIDEO DECODER AMPLIFIER TOINT. FUNCTION SELECTOR SAWIOOTH GENERATOR INPUT EHT TO SATELLITE IF TY 38.9 RECEIVER EP 815 YERTICAL & HORIZONTAL DEFLECTION 85 33 20 AGC \mathcal{M} SYNC POWER SUPPLY ∿ 220¥ STHE JUB 50 Hz BATTERY CHARGER DISPLAT ONLY FOR FM VERSION TY YOL. EIT DC POWER IF/5,5 IF AMPLIFIER



















Q









































CURRENT LIMITER

